PRESSURE WASHER MAINTENANCE INFORMATION

ENGINE OIL

*	Inspect	Daily
*	Change	After First 8 Hours, then every 50 hours. Every 25 hrs in high ambient temps
*	Filter	Every 100 hours

AIR CLEANER

*	Inspect	Every 50 Hours
*	Clean	Every 3 Months

DIESEL ENGINE COOLANT CHECK	Check Daily (Maximum 50% Antifreeze)
BATTERY LEVEL	Check Monthly: 12VDC Burner System: replace battery every 2 years
ENGINE FUEL FILTER	500 hrs or 6 months
SPARK PLUG MAINT.	500 hrs or 6 months
CLEAN FUEL TANKS	Annually
REPLACE FUEL LINES	Annually

PUMP OIL

*	Inspect	Daily
*	Change	After First 25 hours, then every 6 months or 500 hours

Clean Burner Filter	Monthly, more often if fuel quality is poor
Remove Burner Soot	Annually
Burner Adjustment/Cleaning	Annually
Descale Coil	Annually (More often if required)
Replace Spray Nozzle	6 Months
Replace Quick Connects	Annually
Clean Water Screen Filter	Weekly
Clean Float/Supply Tank	Every 6 Months
Replace HP Hose	Annually

BELTS

*	Tighten	6 Months
*	Inspect/Replace	Annually

TRAILER TIRES/BEARINGS	Monthly (Check tires for condition, tighten lug nuts, grease & check bearings

Description	Oil Type	Capacity	Fuel	Capacity
Gas Engine	10W-30	.63 to 3qt	Gasoline	8qt to 7gl
Diesel Engine Kubota	10W-30W API cc/cd	3.25 qt	Diesel #2	7 gl
Pump, Cat	Cat Hydraulic, non-detergent 10w-40	11-42oz		
Pump, AR	Non detergent sae 30w	10-41oz		

Check the engine manufacturer's service guide for additional maintenance items.

While your pressure washer has been produced with quality materials and craftsmanship, you as the owner have certain responsibilities for the correct care of the equipment. Attention to regular preventive maintenance procedures will assist in preserving the performance of your equipment. Contract 3D Pomona @ 909-865-5500. A small investment in preventative maintenance will add many hours to the life of your pressure washer. Do not spray high pressure water onto the machine. *NOT ALL MAINTENANCE ITEMS APPLY TO ALL MACHINES.*